




Ax1



Bx1



Cx1



Dx1




Ex3



Fx3




Gx3







Hx1




1





2



3



4**5**

BELANGRIJK, ZORGVULDIG LEZEN EN BEWAREN VOOR TOEKOMSTIG GEBRUIK.
 Uitsluitend te gebruiken voor huishoudensdoeleinden.
 Reinigen met een vochtige doek.

WICHTIG, SORGFÄLTIG LESEN UND FÜR SPÄTEREN GEBRAUCH AUFBEWAHREN.
 Nur für Haushaltszwecke zu verwenden.
 Mit einem feuchten Tuch reinigen.

IMPORTANT, À LIRE ATTENTIVEMENT ET À CONSERVER POUR RÉFÉRENCE FUTURE.
 À utiliser uniquement à des fins domestiques.
 À nettoyer à l'aide d'un chiffon humide.

maximum weight for the chair: 120kg/seat